

INSTALLAZIONE POMELLO FORD FIESTA MK8

www.rltechdesign.com



Unscrew the knob
counterclockwise.



Once the
knob is unscrewed,
clean well the thread
and the spring from
the grease.
A piece of paper
is enough.



SEE ON LEFT :

It's important to come position the knob. It must be aligned with the plastic part of the original knob.



Paying attention not to lose the position described in the previous point, tighten the knob that you will find in rod after centering the logo. You need a size 3 allen key.



FINAL RESULTS

After positioning the knob with the logos centered and tightened the knob to keep the knob in position result will be as in the photo above.

ATTENTION: do not tighten the nut very tightly because you risk damaging the thread of the shaft of our knob. Tighten until you feel it is tight.